


NOTES TO DESIGNER:

FOR DRILLED PIERS, SET TOP OF SHAFT ELEVATION TO COINCIDE WITH BOTTOM OF MEDIAN BARRIER AT THE C OF THE SHAFT. THE COLUMN SHALL BEGIN AT THE TOP OF THE MEDIAN BARRIER.


SPECIAL CONSIDERATION SHALL BE MADE FOR CONSTRUCTABILITY OF SPREAD AND PILE FOOTINGS.



BAR TYPE

MEDIAN BARRIER RAIL AND COLUMN CONNECTION


FIGURE 7 - 41



NOTES TO DESIGNER:

FOR DRILLED PIERS, SET TOP OF SHAFT ELEVATION TO COINCIDE WITH BOTTOM OF MEDIAN BARRIER AT THE CL OF THE SHAFT. THE COLUMN SHALL BEGIN AT THE TOP OF THE MEDIAN BARRIER.

SPECIAL CONSIDERATION SHALL BE MADE FOR CONSTRUCTABILITY OF SPREAD AND PILE FOOTINGS.



BAR TYPE

MEDIAN BARRIER RAIL AND
COLUMN CONNECTION

FIGURE 7 - 41 M